



1) Slide the hex rod of the spray shield mounting bracket, into the tube of the gun mount bracket and then secure it with the provided star knob.

2) The shields are set at 4" apart at the factory. For a 6" spacing, move them to the outer holes. For a 2" spacing swap the left and right shields.

Part Number 10004506, Eco-Liner Plus Spray Shield Kit